01 PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

(a) Do not attempt to operate this oven with the door open since this can result in harmful exposure to microwave energy. It is important not to break or tamper with the safety interlocks.

(b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.

(c) **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

SPECIFICATIONS

If the apparatus is not maintained in a good state of cleanliness, its surface could be degraded and affect the lifespan of the apparatus and lead to a dangerous situation.

SPECIFICATIONS

Model:	EC9P03XX-S00E00
Rated Voltage:	230V~ 50 Hz
Rated Input Power(Microwave):	1450 W
Rated Output Power(Microwave):	900 W
Rated Input Power(Grill):	1000 W
Rated Input Power(Convection):	2100 W

IMPORTANT SAFETY INSTRUCTIONS

WARNING

To reduce the risk of fire, electric shock, injury to persons or exposure to excessive microwave oven energy when using your appliance, follow basic precautions, including the following:

1. Read and follow the specific:"**PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY**".
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Children should be supervised to ensure that they do not play with the appliance.
4. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
5. WARNING: Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
6. **WARNING:** It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

7. **WARNING:** Liquids and other foods must not be heated in sealed containers since they are liable to explode.
8. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
9. Only use utensils that are suitable for use in microwave ovens.
10. If smoke is emitted, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
11. Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
12. The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
13. Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
14. The oven should be cleaned regularly and any food deposits removed.
15. Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
16. The appliance must not be installed behind a decorative door in order to avoid overheating. (This is not applicable for appliances with decorative door.)
17. Only use the temperature probe recommended for

this oven. (for ovens provided with a facility to use a temperature-sensing probe.)

18. The microwave oven shall not be placed in a cabinet unless it has been tested in a cabinet.
19. The microwave oven must be operated with the decorative door open. (for ovens with a decorative door.)
20. This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- by clients in hotels, motels and other residential type environments;
- farm houses;
- bed and breakfast type environments.

21. The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
22. Metallic containers for food and beverages are not allowed during microwave cooking.
23. The appliance shall not be cleaned with a steam cleaner.
24. The appliance is intended to be used freestanding.
25. The rear surface of appliances shall be placed against a wall.
26. The appliances are not intended to be operated by means of an external timer or separate remote-control system.
27. The temperature of accessible surfaces may be high when the appliance is operating.
28. **WARNING:** When the appliance is operated in the

combination mode, children should only use the oven under adult supervision due to the temperatures generated.

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

TO REDUCE THE RISK OF INJURY TO PERSONS GROUNDING INSTALLATION

▲ DANGER

Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

▲ WARNING

Electric Shock Hazard

Improper use of the grounding can result in electric shock.

Do not plug into an outlet until appliance is properly installed and grounded.

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.

This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded.

If it is necessary to use an extension cord, use only a 3-wire extension cord.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. If a long cord set or extension cord is used:

1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
2) The extension cord must be a grounding-type 3-wire cord.
3) The long cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

▲ CAUTION

Be sure to unplug the appliance from the power supply.

1. Clean the cavity of the oven after using with a slightly damp cloth.
2. Clean the accessories in the usual way in soapy water.
3. The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
4. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
5. Cleaning Tip---For easier cleaning of the cavity walls that the food cooked can touch: Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% microwave power for 10 minutes. Wipe the oven clean using a soft, dry cloth.

05 UTENSILS

▲ CAUTION

Personal Injury Hazard
It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy. See the instructions on "Materials you can use in microwave oven or to be avoided in microwave oven." There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

▲ Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.

MATERIALS YOU CAN USE IN MICROWAVE OVEN

UTENSILS	REMARKS
Browning dish	Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

MATERIALS TO BE AVOIDED IN MICROWAVE OVEN

UTENSILS	REMARKS
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal trimmed utensils	Metal shields the food from microwave energy. Metal trim maycause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

SETTING UP YOUR OVEN 06

Remove the oven and all materials from the carton and oven cavity. Your oven comes with the following accessories:



Glass Tray



Turntable Ring Assembly



Grill Rack(Can not be used in microwave function and must be placed on the glass tray)

Instruction Manual



A) Control panel
B) Turntable Ring Assembly
C) Observation window

D) Door assembly
E) Safety interlock system
F) Oven cavity

NAMES OF OVEN PARTS AND ACCESSORIES

Cleaning the cooking compartment and putting the turntable in place. For new installations, make sure all packaging and shipping tape has been removed. Before using the appliance to prepare food for the first time, you will need to put the turntable in place correctly. You must clean the cooking compartment and accessories.



1) Glass Tray
2) Turntable Ring Assembly



Note:

1. Never use the appliance without the turntable. Make sure that it is properly engaged. The turntable can turn clockwise or anti-clockwise.
2. Never place the glass tray upside down. The glass tray should never be restricted.
3. Both glass tray and turntable ring assembly must always be used during cooking.
4. All food and containers of food are always placed on the glass tray for cooking.
5. Never restrict the movement of the turntable.
6. If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.

▲ COUNTERTOP INSTALLATION

Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.
Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown Mica cover that is attached to the oven cavity to protect the magnetron.

▲ INSTALLATION

1. Select a level surface that provide enough open space for the intake and/or outlet vents.



(1) The minimum installation height is 85cm.
(2) The rear surface of appliance shall be placed against a wall.
Leave a minimum clearance of 30cm above the oven. A minimum clearance of 20cm is required between the oven and any adjacent walls.
(3) Do not remove the legs from the bottom of the oven.
(4) Blocking the intake and/or outlet openings can damage the oven.
(5) Place the oven as far away from radios and TV as possible.
Operation of microwave oven may cause interference to your radio or TV reception.

2. Plug your oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

WARNING: Do not install oven over a range cooktop or other heat-producing appliance. If installed near or over a heat source, the oven could be damaged and the warranty would be void.

The accessible surface may be hot during operation.



08 OPERATION INSTRUCTION

This microwave oven uses modern electronic control to adjust cooking parameters to meet your needs better for cooking.

▲ 1. Clock Setting

When the microwave oven is electrified, the screen will display " : ", and buzzer will ring once.

1) In waiting state, press " Clock/Timer " once, and then the screen displays " 00:00 ".
2) Press " 10min " to adjust the hour figures. The input time should be within 0-23.
3) Press " 1min/10sec ", and the minute figures will flash. The input time should be within 0--59.
4) Press " Clock/Timer " to finish clock setting.

Note: 1) The clock will not work if it is not set when powered.

2) After step 3, if you do not press " Clock/Timer " within 1 minutes, the oven will go back to the previous status automatically.

▲ 2. Kitchen Timer

1) In waiting state, press " Clock/Timer " twice , and the screen displays "00:00".
2) Press number key "10min", "1min" or "10sec" to enter time. The maximum time is 99 minutes 50 seconds.
3) Press " Start/+30sec. " to confirm setting.
4) When the time has elapsed, the buzzer will ring 5 times. If the clock has been set (24-hour system), the screen will display the current time.

Note: 1) When the kitchen timer is working, the oven does not work.

2) Pressing " Start/+30sec " can not increase time.

▲ 3. Microwave Cooking

1) In waiting state, press " Cook Time", and " 0:00 " will display.
2) Press number key "10min", "1min" or "10sec" to enter cooking time. The maximum time is 99 minutes 50 seconds.
3) Press " Power Level " to choose power level. There are 11 power levels, including P100, P90, P80, P70, P60, P50, P40, P30, P20, P10 and P0.
4) Press the " Start/+30sec "key to start cooking.
5) Press " STOP/Cancel " or open the oven door to stop cooking during cooking process.

Note: In standby state, press the "10min", "1min" and "10sec" directly to start microwave cooking with P100 power in corresponding time.

▲ 4. Grill Cooking

1) Press " Grill " once, and" Gr " will flash on the screen.
2) Press " Start/+30sec. " to confirm the function or press "10min", "1min" or "10sec" to adjust the cooking time. (The maximum cooking time is 99 minutes 50sec).
3) Press the " Start/+30sec. "key to start cooking.

Note: 1) If half the grill time passes, the oven sounds to remind you to turn the food over. In order to have a better effect of grilling food, you can turn the food over, close the door and then press " Start/+30sec. " to continue cooking.
If no operation, the oven will work automatically.
2) In the cooking process, when you increase or reduce the time, half time prompt is no affected.

▲ 5. Convection Cooking

1) Press " Conv. " once. and "150 " will flash on the screen.
2) Press "Conv. " repeatedly to choose temperature from 150 to 240.
3) Press the " Start/+30sec. " to confirm the temperature.
4) If you press " Start/+30sec. " again, the oven will start preheating. When the preheating temperature is reached, the buzzer will sound twice. You can open the oven door and place food in it. After that, press number keys to enter cooking time.
Otherwise, after step 3, you can press number keys to enter cooking time. (The maximum time is 99 minutes and 50 seconds.)
5) Press the " Start/+30sec" to start working.

▲ 6. Multi-Stage Cooking

Two stages can be maximumly set. If one stages is defrosting, it should be put in the first stage automatically. The buzzer will ring once after each stage and the next stage will begin.

Note: Kitchen Timer, Auto menu or Preheating cannot be set as one of the multi-stage.

Example: if you want to defrost the food for 5 minutes, then grill them for 2 minutes and 30 seconds. You can follow these steps.

1) Press " Time Defrost " once, and the screen will display "0:00".
2) Press number keys to adjust the defrost time of 5 minutes.
3) Press " Grill " once.
4) Press number keys to adjust the defrost time of 2 minutes and 30 seconds.
5) Press " Start/+30sec " to start cooking.

▲ 7.Combi.Cooking

1) Press "Combi." once, the screen will display "C-1", and press "Combi." repeatedly to choose the power you want, and "C-1", "C-2" "C-3", o "C-4" will display. After that, press number keys to adjust the cooking time. (The maximum cooking time is 99 minutes and 50 seconds)
2) Press "Start/+30sec " to start cooking.
3) Press " STOP/Cancel " or open the oven door to stop cooking during cooking process.

Example: If you want to use combination to cook (C-1) for 10 minutes, you can operate the oven as the following steps.

1) Press "Combi." once, and the screen displays "C-1"
2) Adjust the cooking time until the oven displays "10:00".
3) Press " Start/+30Sec." to start cooking.

Note: Combination instructions

Instructions	Display	Microwave	grill	Convection
1	C-1	●		●
2	C-2	●	●	
3	C-3		●	●
4	C-4	●	●	●

▲ 8. Defrost by Time

1) In waiting state, press "Time Defrost " once, a nd the screen displays "0:00".
2) Press number key "10min", "1min" or "10sec" to enter cooking time. The maximum time is 99 minutes 50 seconds.
3) Press" Start/+30Sec. " key to start defrosting.

Note: If half the time passes, the buzzer will sound once.

▲ 9. Auto Menu

1) In waiting state, press "Air Fry" once, and "AF01" will display.
2) Press "Air Fry" repeatedly or press"10min" or "10sec" to choose the menu from "AF01" to "AF10".
3) Press " Start/+30Sec. "to start cooking.

Auto Menu

Sr. No.	Name	Display	Display
1	Slim food	SF	SF01-SF30
2	Bread Basket	bb	bb01-bb20
3	Tadka/Curry	tC	tC01-tC58
4	Oversea Dishes	oS	oS01-oS40
5	India's Daily	Id	Id01-Id57
6	Breakfast/Snacks	bS	bS01-bS23
7	Desserts/Soups	dS	dS01-dS43
8	Paneer/Ghee/Curd	PG	PG01-PG17
9	Air Fry	AF	AF01--AF10

Air Fry Menu

Sr. No.	Name
AF01	Frozen Chicken Nuggets
AF02	Frozen Cheese sticks
AF03	Frozen Fried Squid
AF04	Frozen Onion Ring
AF05	Frozen Breaded Prawns
AF06	Frozen Fried Chicken Cutlet
AF07	Frozen vegetable Cutlets
AF08	Grilled Fresh Fish Fillets
AF09	Frozen Buffalo Chicken wings
AF10	Frozen Fried Chicken Wings

▲ 10. Quick Microwave cooking

1) In standby state, press " Start/+30sec. " to start cooking with 100% power for 30 seconds. Each added press will increase 30 seconds.

▲ 11. Lock-out Function for Children

Lock: In standby state, press " Stop/Cancel " for 3 seconds. There will be a "beep" denoting entering into the children-lock state and the lock indicator will light.

Lock quitting: In locked state, press " Stop/Cancel "for 3 seconds. There will be a "beep" denoting that the lock is released , and the lock indicator will disappear.

▲ 12. Deodoriser

1) In standby state, press " Deodoriser ", and the screen displays "dE" .
2) Press " Start/+30sec. " key to start working.

▲ 13. Steam Clean

1) In standby state, press "Steam Clean", and the screen displays "SC".
2) Press " Start/+30sec. " key to start working.

TROUBLE SHOOTING 09

Normal	
Microwave oven interfering TV reception	Radio and TV reception may be interfered when microwave oven operating. It is similar to the interference of small electrical appliances, like mixer, vacuum cleaner, and electric fan. It is normal.
Dim oven light	In low power microwave cooking, oven light may become dim. It is normal.
Steam accumulating on door, hot air out of vents	In cooking, steam may come out of food. Most will get out from vents. But some may accumulate on cool place like oven door. It is normal.
Oven started accidentally with no food in.	It is forbidden to run the unit without any food inside. It is very dangerous.

Trouble	Possible Cause	Remedy
Oven cannot be started.	(1) Power cord is not plugged in tightly.	Unplug. Then plug again after 10 seconds.
	(2) Fuse blowing or circuit breaker works.	Replace fuse or reset circuit breaker (repaired by professional per onnel of our company)
	(3) Trouble with outlet.	Test outlet with other electrical appliances.
Oven does not heat.	(4) Door is not closed well.	Close door well.

According to Waste of Electrical and Electronic Equipment (WEEE) directive, WEEE should be separately collected and treated. If at any time in future you need to dispose of this product please do NOT dispose of this product with household waste. Please send this product to WEEE collecting points where available.